

Mayer M000

Setting instructions

Setting steps reproduced from Mayer with permission confirmed by the distributor. This guide is not a complete machine operating manual. Follow the operating and safety instructions for the specific machine before work.

MILESTATE · 2026-09-11


Step 1: Adjust the turntable to the appropriate pot size using the crank handle



Step 2: Throttle the turntable speed




Step 3: Move the drill motor to the lowest position




The upper holding jaw and the ejector are now standing apart



Step 4: Open the clamp and use the crank to set the appropriate width



The uppermost pot edge now rests on the uppermost holding jaw



Step 5: Secure the clamp




Step 6: Move the drill motor up and remove the cover



Step 7: To adjust the lower pot diameter, loosen the locking screw with an open-end wrench



Step 8: Position the lower holding jaw below the edge of the pot



Step 9: Tighten the locking screw again



Step 10: Adjust the distance between the pots so that the upper holding jaw and the ejector are between the last two pots



Step 11: Open clamp



Step 12: Support with your hand and adjust the height



Step 13: Once the correct position is achieved, close the clamp and reattach the cover. And your pot dispenser is ready!

