

Mayer M100

Setting instructions


Setting steps reproduced from Mayer with permission confirmed by the distributor. This guide is not a complete machine operating manual. Follow the operating and safety instructions for the specific machine before work.

MILESTATE · 2026-09-11

Step 1: Loosen the cover on the turntable and slide it to the back




Step 2: Adjust the turntable to the desired pot size using a socket wrench



Step 3: Reduce the turntable speed and move the drill motor to the lower position




The upper holding jaw and the ejector are now standing apart




Step 4: Insert the desired pots




Step 5: Use the crank to set the appropriate width




The upper edge of the pot now rests on the uppermost holding jaw



Step 6: Take out the pots




... and move the drill motor upwards




Step 7: Reinsert the pots and loosen the locking screws of the lower retaining jaw




Step 8: Adjust the lower holding jaws and position below the edge of the pot



Step 9: Tighten the locking screws



Step 10: Adjust the height of the pots



So that the upper holding jaw and the ejector are between the last two pots



Step 11: Close the covers and your perfectly adjusted double-sided dispenser M100 is ready

